

STANDARD SIZES

CCI P/N	SIZE L X W X H (I.D.)	FOAM CODE	NUMBER / CASE
3631	4 x 4 x 2"	A	81
3080-1	7 x 5 x 1-1/2"	A	58
3090-2	7 x 5 x 2-1/2"	B	36
3180-3	9 x 7-1/2 x 1-1/2"	A	32
3190-4	9 x 7-1/2 x 2-1/2"	B	18
3220-5	10-1/2 x 8-1/2 x 1-1/2"	A	22
3230-6	10-1/2 x 8-1/2 x 2-1/2"	B	14
3310-7	12-1/2 x 10-1/2 x 1-1/2"	A	15
3320-8	12-1/2 x 10-1/2 x 2-1/2"	B	9
3500-10	15-1/2 x 12-1/2 x 2-1/2"	B	4
3420-13	14-7/8 x 6-5/8 x 2"	A	15
3610-12	20-1/2 x 15-1/2 x 2-1/2"	B	No Case

CCI P/N	SIZE L X W X H (I.D.)	FOAM CODE
3641	5 -3/4 x 6-1/4 x 2-1/2"	B
3651	7 x 7 x 5"	X
3661	8 x 8 x 1-1/2"	A
3671	9-1/8 x 14-3/4 x 1-1/2"	A
3681	9 x 14 x 2-1/2"	B
3691	10 x 10 x 4-1/4"	B
3701	11 x 7-3/4 x 2-7/8"	B
3711	12 x 12 x 3"	B
3721	13-1/2 x 13-1/2 x 2"	A
3490-9	15-1/2 x 12-1/2 x 1-1/2"	A
3525-14	16 x 12-1/4 x 3-1/2"	B
3731	18 x 12 x 3-1/2"	B

CCI P/N	SIZE L X W X H (I.D.)	FOAM CODE
3763	16-1/2 x 10-1/2 x 6-1/2"	X
3762	17-1/4 x 10-1/2 x 5-3/4"	X
3568-15	18-7/8 x 17-5/8 x 1-3/4"	A
3765	19-1/4 x 16-3/4 x 5-5/8"	X
3741	20 x 19 x 2"	A
3767	20-1/4 x 17-3/4 x 5-5/8"	X
3600-11	20-1/2 x 15-1/2 x 1-1/2"	A
3766	21-1/4 x 12-1/2 x 4-1/2"	X
3751	23 x 16-1/2 x 5"	X
3764	26-3/4 x 6-1/4 x 6"	X
3768	20-1/4 x 17-1/2 x 4"	X

CFP options available by adding "CFP" to the beginning of part numbers listed above

Example: CFP3631 = 3631 mailer in Conductive Fluted Plastic

Add "-M" to part number for knocked down mailer with no foam

Example: 3631-M = 3631 mailer shipped knocked down and without foam

Add "L" for top foam to be laminated, "2L" for top and bottom foam to be laminated

Example: 3631-2L = 3631 mailer with foam laminated top and bottom

STATIC DISSIPATIVE CONVOLUTED FOAM

Foam fingers will compress more with longer fingers for more weight

FOAM CODES
A = 3/4"F x 1/4"B
B = 1-1/8"F x 3/8"B
X = Customize

For more information visit www.corstat.com/Mailers

Rule to Determine Mailer Height ID:

Finger + Finger + PCB = X

X - 1/4" to 1/2" (for compression) = Mailer ID

Example: "B" Foam = 1-1/8" Finger and the PCB = 3/4"


1-1/8" (F) + 1-1/8" (F) + 3/4" (PCB) = 3"

3" - 1/2" = 2-1/2" Mailer ID

Allow 1"-2" on all 4 Sides of the PCB to Determine the Length and Width

Example: PCB = 7" x 5"

Mailer ID = 8" x 6"



F = Finger B = Base PCB